





P - Instruções de montagem F - Instructions de montage E - Instrucciones de montaje
 GB - Installation instructions D - Montageanweisungen

Watt	C	L	A	F1	F2
36	1230	266	85	1040	116
58	1530	266	85	1340	116
28/54	1194	266	80	1040	116
35/49/80	1494	266	80	1340	116





P - Instruções de montagem F - Instructions de montage E - Instrucciones de montaje
 GB - Installation instructions D - Montageanweisungen



P - Instruções de montagem F - Instructions de montage E - Instrucciones de montaje
 GB - Installation instructions D - Montageanweisungen

Watt	C	L	A	F1	F2
36	1230	266	85	1040	116
58	1530	266	85	1340	116
28/54	1194	266	80	1040	116
35/49/80	1494	266	80	1340	116



P - Instruções de montagem F - Instructions de montage E - Instrucciones de montaje
 GB - Installation instructions D - Montageanweisungen

